




STARTER SAWAFUJI

www.auto-marco.com



*Experience
Service
Trust*

O.E.M names and numbers are used for reference purposes only.




SAWAFUJI-KOMATSU

		
<p align="center">SSW001</p>	<p align="center">SSW002</p>	<p align="center">SSW003</p>
<p>Replace1: 0351-702-0271 0351-702-0810 0351-702-0812 0351-702-0820 Replace2: 600-813-4811 600-813-4822 References: 30196 Applications: KOMATSU SA6D155 Descriptions: 11KW 24V 11T</p>	<p>Replace1: 0351-702-0221 0351-702-0252 0351-702-0610 0351-702-0660 Replace2: 600-813-3912 600-813-3922 References: 19949 Applications: KOMATSU S6D125 SA6D140 Descriptions: 11KW 24V 12T</p>	<p>Replace1: 0351-702-0071 0351-702-0710 0351-702-0720 0351-702-0730 Replace2: 600-813-3942 600-813-3951 References: 19921 Applications: KOMATSU Descriptions: 11KW 24V 11T</p>
		
<p align="center">SSW004</p>	<p align="center">SSW005</p>	
<p>Replace1: 0351-702-0230 0351-702-0231 0351-702-0252 0351-702-0630 Replace2: 600-813-3930 600-813-8810 References: 19949 Applications: KOMATSU SA6D108 Descriptions: 11KW 24V 12T</p>	<p>Replace1: 0351-702-0510 0351-702-0520 0351-702-0560 0351-702-0590 Replace2: 600-813-3772 600-813-3862 References: 19967 Applications: KOMATSU SA6D170 NT855 Descriptions: 11KW 24V 11T</p>	












SAWAFUJI-HINO

		
<p align="center">SSW006</p>	<p align="center">SSW007</p>	<p align="center">SSW008</p>
<p>Replace1: 0350-502-0013 0350-502-0016 0350-502-0242 Replace2: 28100-2622B 28100-2624 References: Applications: HINO J08C with wire Descriptions: 4.5KW 24V 11T</p>	<p>Replace1: 0355-502-0016 0355-502-0019 0355-502-0217 Replace2: 28100-2622B 28100-2623 References: 19956 Applications: HINO J05C J07C J08C Descriptions: 4.5KW 24V 11T</p>	<p>Replace1: 0355-502-0211 0355-502-0212 Replace2: 28100-78090 References: Applications: HINO DUTRO Descriptions: 4.5KW 24V 11T</p>
		
<p align="center">SSW009</p>	<p align="center">SSW010</p>	<p align="center">SSW011</p>
<p>Replace1: 0365-602-0025 0365-602-0026 0365-602-0028 0365-602-0060 Replace2: 28100-2875 28100-2951C References: Applications: HINO P11C Descriptions: 6.0KW 24V 11T</p>	<p>Replace1: 0365-602-0011 0365-602-0012 0365-602-0014 0365-602-0016 Replace2: 28100-2865 28100-2865A References: 19102 Applications: HINO E13C Descriptions: 6.0KW 24V 11T</p>	<p>Replace1: 0365-502-0023 0365-502-0026 0365-502-0027 Replace2: 28100-78110 28100-78112 References: Applications: HINO S05C Descriptions: 5.0KW 24V 11T</p>
		
<p align="center">SSW012</p>	<p align="center">SSW013</p>	<p align="center">SSW014</p>
<p>Replace1: 0365-502-0013 0365-502-0017 Replace2: 28100-2891A 28100-2894 References: 19271 Applications: J05D J07E J08E with wire Descriptions: 5.0KW 24V 11T</p>	<p>Replace1: 0350-502-0010 0350-502-0019 0350-502-0041 0350-502-0048 Replace2: 28100-1821 28100-1823 Applications: HINO EH500 EH700 H06C H07C H07D Descriptions: 4.5KW 24V 11T</p>	<p>Replace1: 0350-552-0510 0350-552-0511 0350-552-0512 0350-552-0513 Replace2: 28100-2270 28100-2271 References: 19947 Applications: HINO EH500 EH700 H06C H07C H07D Descriptions: 5.5KW 24V 11T</p>












SAWAFUJI-HINO

		
<p align="center">SSW015</p>	<p align="center">SSW016</p>	<p align="center">SSW017</p>
<p>Replace1: 0350-602-0110 0350-602-0119 Replace2: 28100-1740 28100-1780 References: Applications: HINO EM100 EF750 Descriptions: 6.0KW 24V 11T</p>	<p>Replace1: 0350-602-0270 Replace2: 28100-2000 References: Applications: HINO EF750 EM100 Descriptions: 7.0KW 24V 11T</p>	<p>Replace1: 0350-602-0234 Replace2: 28100-2000 References: Applications: HINO EM100 EF750 Descriptions: 8.0KW 24V 11T</p>
		
<p align="center">SSW018</p>	<p align="center">SSW019</p>	<p align="center">SSW020</p>
<p>Replace1: 0350-702-0024 0350-702-0270 Replace2: 28100-1020 28100-1490 References: 19968 Applications: HINO EK100 EK130 Descriptions: 6.0KW 24V 11T</p>	<p>Replace1: 0350-702-0021 0350-702-0180 0350-702-0220 0350-702-0226 Replace2: 28100-1490 28100-1790 References: Applications: HINO EK100 EK130 Descriptions: 7.0KW 24V 11T</p>	<p>Replace1: 0350-702-0224 Replace2: 28100-1790 28100-1791 References: Applications: HINO EK100 EK130 Descriptions: 8.0KW 24V 11T</p>
		
<p align="center">SSW021</p>	<p align="center">SSW022</p>	<p align="center">SSW023</p>
<p>Replace1: 0350-602-0812 0350-602-0420 Replace2: 28100-1081 28100-1590 References: Applications: HINO ED100 ER100 Descriptions: 6.0KW 24V 13T</p>	<p>Replace1: 0350-402-0210 0350-402-0310 0350-402-0330 0351-402-0111 Replace2: 28100-1890 281001894 References: Applications: HINO W04D Descriptions: 4.5KW 24V 11T</p>	<p>Replace1: 0350-402-0210 0350-402-0229 0350-402-0310 Replace2: 28100-1890 28100-1894 References: Applications: HINO W04D 1W Descriptions: 5.0KW 24V 11T</p>





SAWAFUJI-HINO

		
<p align="center">SSW024</p>	<p align="center">SSW025</p>	<p align="center">SSW026</p>
<p>Replace1: 0350-502-0020 0350-502-0030 Replace2: 28100-1813 28100-2090 References: Applications: HINO W06E W06D Descriptions: 4.5KW 24V 11T</p>	<p>Replace1: 0350-552-0320 0350-552-0350/0358 Replace2: 28100-2140 28100-1854 References: Applications: HINO W06E W06D Descriptions: 5.5KW 24V 11T</p>	<p>Replace1: 0300-552-0010 0300-552-0011 Replace2: 28100-1400A 28100-1400B References: Applications: HINO DK10 DS50 DS70 EB100 EB200 Descriptions: 5.0KW 13T</p>
		
<p align="center">SSW027</p>	<p align="center">SSW042B</p>	<p align="center">SSW022B</p>
<p>Replace1: 0300-602-0312 Replace2: 28100-1230 28100-1590 References: Applications: HINO EB300 EB400 Descriptions: 6.0KW 24V 13T</p>	<p>Replace1: 0350-702-0390 Replace2: 23300-97517 References: Applications: Hino P11C Descriptions: 6.0KW 24V 11Tφ46</p>	<p>Replace1: 0350-402-0252 0350-402-0210 Replace2: 28100-1542 References: 19954 Applications: Hino W04D Descriptions: 4.5KW 24V 11Tφ40</p>
		
<p align="center">SSW048</p>	<p align="center">SSW049</p>	<p align="center">SSW050</p>
<p>Replace1: 0340-702-0060 Replace2: 28100-1290 References: 19952 Applications: Hino Descriptions: 7.0KW 24V 11T</p>	<p>Replace1: Replace2: 07C2 References: Applications: Descriptions: 4.5KW 24V 11T</p>	<p>Replace1: 0350-602-0036 0350-602-0030 0350-602-0031 0350-602-0032 Replace2: 28100-1520B 28100-1472 References: 114344 Applications: Hino EF750 Descriptions: 24V 6.0KW 11T Φ47.5</p>



SAWAFUJI-HINO

		
SSW051	SSW050	
<p>Replace1: 0330-602-0113 0330-602-0110 0350-702-0025 0350-702-0224</p> <p>Replace2: 28100-1020 281001491A</p> <p>References: 114345 19968</p> <p>Applications: Hino EK100</p> <p>Descriptions: 24V 6.0KW 11T Φ47.5</p>	<p>Replace1: 0350-602-0030 0350-602-0036 0350-602-0411</p> <p>Replace2: 28100-1520 28100-1472</p> <p>References:</p> <p>Applications: EM100,EP100,EL100,EF300, EF700,EF550,EF750</p> <p>Descriptions: 8.5kW 24V 11T</p>	











SAWAFUJI-NISSAN

<p align="center">SSW029</p>	<p align="center">SSW030</p>	<p align="center">SSW031</p>
<p>Replace1: 0351-602-0091 0351-702-0160 0350-702-0011 Replace2: 23300-97001 23300-97002 References: Applications: NISSAN RD8 Descriptions: 6.0KW 24V 11T</p>	<p>Replace1: 0351-602-0022 Replace2: 23300-97061 23300-97100 References: Applications: NISSAN RD8 Descriptions: 7.0KW 24V 11T</p>	<p>Replace1: 0351-602-0011 Replace2: 23300-97634 23300-97100 References: Applications: NISSAN RD8 Descriptions: 8.0KW 24V 11T</p>
<p align="center">SSW028</p>	<p align="center">SSW032</p>	<p align="center">SSW033</p>
<p>Replace1: 0351-602-0010 0351-602-0016 Replace2: 23300-96004 23300-96026 References: 19930 Applications: NISSAN P6 PD6 PE6 Descriptions: 6.0KW 24V 11T</p>	<p>Replace1: 0350-602-0390 0350-602-0233 0350-602-0470 0350-602-0230 Replace2: 23300-97505 23300-97507 References: Applications: NISSAN RF8 Descriptions: 6.0KW 24V 11T</p>	<p>Replace1: 0350-702-0390 Replace2: 23300-97508 References: Applications: NISSAN RF8 Descriptions: 7.0KW 24V 11T</p>
<p align="center">SSW034</p>	<p align="center">SSW035-24V</p>	<p align="center">SSW036</p>
<p>Replace1: 0350-802-0020 Replace2: 23300-97203 References: Applications: NISSAN RF8 Descriptions: 8.0KW 24V 11T</p>	<p>Replace1: 0350-502-0031 0350-502-00130 0350-502-00131 Replace2: 23300-Z5517 References: Applications: NISSAN FD6 FE6 Descriptions: 5.5KW 24V 11T</p>	<p>Replace1: 0350-502-0110 Replace2: 23300-Z5578 References: Applications: NISSAN FD6 FE6 Descriptions: 4.5KW 24V 11T</p>





SAWAFUJI-NISSAN

		
<p align="center">SSW037</p>	<p align="center">SSW038</p>	<p align="center">SSW039</p>
<p>Replace1: 0357-502-0010 Replace2: 23300-Z5519 References: NISSAN FD6 FE6 Applications: Descriptions: 3.0KW 12V 11T</p>	<p>Replace1: 0350-602-0260 0350-602-0330 0350-602-0380 0350-602-0460 Replace2: 23300-96504 23300-95500 References: QD04A Applications: NISSAN P6 PF6 NF6 PG6 Descriptions: 6.0KW 24V 11T</p>	<p>Replace1: 0350-602-0340 Replace2: 23300-95009 23300-95015 References: QD04C Applications: NISSAN NE6 Descriptions: 5.0KW 24V 11T</p>
		
<p align="center">SSW040</p>	<p align="center">SSW041</p>	<p align="center">SSW042</p>
<p>Replace1: 0350-602-0610 Replace2: 23300-Z6007 References: Applications: NISSAN MD92 Descriptions: 5.0KW 24V 11T</p>	<p>Replace1: 0300-402-0510 0300-552-0510 Replace2: 23300-90006 23300-90007 References: Applications: NISSAN UD63 UD43 Descriptions: 6.0KW 24V 11T</p>	<p>Replace1: 0350-702-0390 0350-702-0391 0350-702-0610 0350-702-0612 Replace2: 23300-97508 23300-97510 References: QD029B Applications: NISSAN RG8 Descriptions: 6.0KW 24V 11T</p>
		
<p align="center">SSW043</p>	<p align="center">SSW046</p>	
<p>Replace1: 0350-602-0331 Replace2: 23300-96078 23300-96106 References: Applications: NISSAN PD604 Descriptions: 7.0KW 24V 11T</p>	<p>Replace1: 0350-602-0010 0350-602-0211 Replace2: References: Applications: Nissan Sawafuji Descriptions: 5.5KW 24V 11T</p>	



SAWAFUJI-MITSUBISHI

		
SSW045	SSW047	
<p>Replace1: 04301-36100 Replace2: 0350-602-0050 References: Applications: Mitsubishi S6B Descriptions: 6.0KW 24V 11Tφ45</p>	<p>Replace1: 0340-552-0120 0340-552-0121 0340-552-0110 Replace2: 04301-36010 04301-38000 References: 19964 Applications: Mitsubishi Marine/ Industrial Descriptions: 6.0KW 24V 11T</p>	

